

# RootBarrier™ Molebarrier 110 / 400

## Installation guide

### Step 1: Preperation

Prepare the ground and rake if necessary. Ensure that the ground is free of rubble, stones and other sharp object before laying Molebarrier to prevent damage to the material. The Molebarrier must be installed approximately 5-10 cm below ground level.

### Step 2: Roll out

Unroll the MoleBarrier horizontally on the ground without any pressure. If several rolls are laid side by side, ensure that there is an overlap of at least 15 cm.

### Step 3: Secure

To secure the material, use at least 2 pins (PT200) per linear metre.

### Step 4: Rising edges

To prevent moles from entering the garden sideways between the grass layer and the MoleBarrier, let the edges of the grid rise till the grass layer.

### Step 5: Folding and digging in

The ends of the MoleBarrier should be folded at a 90 degree angle and has to be dug in vertically 50 to 100 cm, depending on the groundwater level.

### Step 6: Cover

The MoleBarrier must be covered with approximately 5-10 cm of soil.

