

RootBarrier™ BioCovers® Installation guide

Step 1: Preparation

Prepare the ground and rake if necessary. Ensure that the ground is free of rubble, sharp stones, weeds and trees before laying BioCovers® to prevent damage to the fabric.

! Do not install on concrete, cement or very alkaline ground (pH > 12).

Step 2: Roll out

Roll out BioCovers®. If several rolls are laid side by side, ensure there is an overlap of at least 15 cm.

Step 3: Secure

Secure the fabric with BioCovers® pins or dig the ends of the mat into the ground (at least 15 cm deep). Use at least 1 pin per linear metre in both the length and width directions. The overlap and the centre of the fabric must also be secured.

Step 4: Cut

Using sharp scissors or a knife, make an "Y-shaped" cut above an existing plant or in the spot where the new plant is to be placed.

Step 5: Plant

Work BioCovers® gently over existing plants or plant through with new ones.

BioCovers® is UV-resistant and does not need to be covered.

