

## RootBarrier™ HDPE Installation guide

### Step 1: Preparation

Dig a trench as deep as the width of the roll.

### Step 2: Roll out

Unroll RootBarrier™ HDPE. Avoid damaging the material. If several rolls are to be used side by side, see 'Step 4: Connect'.

### Step 3: Install

Place vertically towards the roots. If used for bamboo, place the top of RootBarrier™ HDPE 5 cm above the ground level.

### Step 4: Connect

- Drill the required number of holes in both HDPE 2mm root screen edges.
- Remove the screws from the HDPE aluminum joining strips.
- Place one HDPE aluminum strip on each side of the two HDPE 2mm root barrier.
- Use the screws to fix the HDPE root barrier and the HDPE aluminum joining strips together

