

## Dupont™ Plantex® Cocomat Installation guide

### Step 1: Preparation

Prepare the ground and rake if necessary. Ensure that the ground is free of rubble, sharp stones and weeds before laying Plantex® Cocomat to prevent damage to the fabric.

### Step 2: Roll out

Roll out Plantex® Cocomat. If several rolls are laid side by side, ensure there is an overlap of at least 10 cm.

### Step 3: Secure

Apply at least 2 pins per running. On large unplanted areas weigh down Plantex® Cocomat with stones or with the new plants to ensure that no movement occurs whilst planting through.

### Step 4: Cut

Using sharp scissors or a knife, make an "X-shaped" cut above an existing plant or in the spot where the new plant is to be placed.

### Step 5: Plant

Work Plantex® Cocomat gently over existing plants or plant through with new ones.

### Step 6: Cover

Plantex® Cocomat does not need to be covered, since the product itself is already covered with the coconut fibre layer.

