

# RootBarrier™ T100 Installation guide

## Step 1: Preparation

Prepare the ground and rake if necessary. Ensure that the ground is free of rubble, sharp stones and weeds before laying RootBarrier™ T100 to prevent damage to the fabric.

## Step 2: Roll out

Roll out RootBarrier™ T100. If several rolls are laid side by side, ensure there is an overlap of at least 10 cm.

## Step 3: Secure

Apply at least 2 pins per running. On large unplanted areas weigh down RootBarrier™ T100 with stones or with the new plants to ensure that no movement occurs whilst planting through.

## Step 4: Cut (If applicable)

Using sharp scissors or a knife, make an "X-shaped" cut above an existing plant or in the spot where the new plant is to be placed.

## Step 5: Plant (If applicable)

Work RootBarrier™ T100 gently over existing plants or plant through with new ones.

## Step 6: Cover

RootBarrier™ T100 must be covered with at least a 5 cm layer of mulch e.g. bark, straw, gravel, decorative chippings etc. The top cover should be thick enough to fully cover the fabric, preventing sun light from reaching the fabric. On the other side it should not be too thick neither so that the mulch may dry out during sunny days. This will slow down the decomposition of mulch.

